

Perfect Pass Jump Setting Charts

Initial Segment Balance Settings for 51 km/h

Distance in m	21	24	27	30	34	37	40	43	46	49	52	55	Weight in kg
41	H	I	J	J	K	L	L	M	M	N	O	O	41
45	I	I	J	K	K	L	L	M	N	N	O	P	45
50	I	J	J	K	K	L	M	M	N	O	O	P	50
54	I	J	J	K	L	L	M	N	N	O	O	P	54
59	I	J	K	K	L	M	M	N	N	O	P	P	59
64	J	J	K	L	L	M	M	N	O	O	P	Q	64
68	J	K	K	L	L	M	N	N	O	P	P	Q	68
73	J	K	K	L	M	M	N	N	O	P	P	Q	73
77	J	K	L	L	M	M	N	O	O	P	Q	Q	77
82	N	N	O	O	P	Q	Q	R	S	S	T	T	82
86	N	O	O	P	P	Q	R	R	S	T	T	U	86
91	N	O	P	P	Q	Q	R	S	S	T	U	U	91
95	O	O	P	Q	Q	R	R	S	T	T	U	V	95
100	O	P	P	Q	R	R	S	S	T	U	U	V	100
Distance in m	21	24	27	30	34	37	40	43	46	49	52	55	

Initial Segment Balance Settings for 48 km/h

Distance in m	21	24	27	30	34	37	40	43	46	49	52	55	Weight in kg
41	H	I	I	J	K	K	L	M	M	N	N	O	41
45	I	I	J	J	K	L	L	M	M	N	O	O	45
50	I	I	J	K	K	L	L	M	N	N	O	O	50
54	I	J	J	K	K	L	M	M	N	N	O	P	54
59	I	J	J	K	L	L	M	M	N	O	O	P	59
64	I	J	K	K	L	L	M	N	N	O	O	P	64
68	J	J	K	K	L	M	M	N	N	O	P	P	68
73	J	K	K	L	L	M	N	N	O	O	P	Q	73
77	J	K	K	L	M	M	N	N	O	P	P	Q	77
82	M	N	N	O	P	P	Q	Q	R	S	S	T	82
86	N	N	O	O	P	Q	Q	R	R	S	T	T	86
91	N	O	O	P	P	Q	R	R	S	S	T	U	91
95	N	O	P	P	Q	Q	R	S	S	T	T	U	95
Distance in m	21	24	27	30	34	37	40	43	46	49	52	55	